

Utilisation de la carte "SmartLight"

NOTICE TECHNIQUE



MISE EN PLACE

Placer la carte sur la surface à éclairer. La carte n'est utilisable qu'en intérieur entre 5°C et 50°C.



ALIMENTATION

Brancher un chargeur jack 9 à 12V dans le connecteur prévu à cet effet. Pour modifier le programme brancher un chargeur mini USB dans la carte bleue.



LAMPE

Dans le bornier à vis quadruple, brancher les fils rouge et noir de la lampe IKEA Navlinge respectivement dans les bornes L+ et L-.



CHANGEMENT DE MODE

Appuyer sur les deux boutons en même temps ou sur les boutons ON/OFF de la télécommande pour alterner entre les deux modes. La led rouge indique le mode automatique. La led verte indique le mode manuel.



MODE MANUEL

A l'aide des deux boutons, il est possible de régler la lampe à la puissance lumineuse souhaitée. SW1 ou le bouton + de la télécommande pour l'augmenter et SW2, ou le bouton - pour la baisser.



PREMIÈRE UTILISATION

La carte possède un mode manuel et un mode automatique. Lors de la première utilisation, elle démarrera en mode manuel.



PARAMÉTRAGE

En mode automatique, utiliser un tournevis pour régler le potentiomètre (RV1) pour que la lampe s'allume et s'éteigne à une luminosité plus ou moins élevée



ÉCLAIRAGE AUTOMATIQUE

La puissance lumineuse de la lampe est celle qui a été configurée en mode manuel.



OPTIONS TÉLÉCOMMANDE

Uniquement avec la télécommande, appuyer sur le bouton "R", activera/désactivera le fondu en mode automatique. La led jaune indique que le fondu est activé. Le bouton "W" permet d'éteindre la lampe tout en conservant le dernier niveau de luminosité en mémoire. Ce niveau sera appliqué au prochain allumage. La led violette indique que la lampe est éteinte

"Smart Light" board using

SPECIFICATION SHEET



PRELIMINARY SETUP

First, place the main board on the surface to be lighted. The board can only be used inside between and 5°C and 50°C.



POWER SUPPLYING

Plug in a power supply jack (9 to 12V) into the specific connector. To modify the program plug in a mini USB charger into the blue board.



LAMP

Plug the red and black wires of the IKEA Navlinge lamp in the L+ and L- connector of the 4-pin screw terminal block.



SWITCH MODE

Press the buttons at the same time to switch between manual and automatic modes. Green led shows manual mode and red led shows automatic mode.



MANUAL MODE

Using the two switches of the main board or the + and - buttons of the remote, it is possible to set the bright level. (SW1 to increase and SW2 to decrease)



FIRST USE

The board have both manual and automatic mode. The board first starts in manual mode.



CONFIGURATION

In automatic mode, adjust the potentiometer (RV1) with an appropriate screwdriver to select the luminosity level needed to turn ON/OFF the lamp.



AUTOMATIC LIGHTNING

The bright level is the same as the one configured in manual mode.



REMOTE CONTROL OPTIONS

Only with the IR remote control, it is possible to turn ON/OFF the fading option by using the "R" button of the remote. A yellow led indicates that fading option is ON. Press the "W" button to turn ON/OFF the light. The last bright level is stored in memory. This level will be used when the light is turned ON. A purple led indicates that the light is OFF.